

Alien Pinball – Setup Instructions

Step 1:

Start with folded game laying on a flat surface, with the locking pin (A) facing up.




Fig. 1: step 1, starting position

Step 2:

Pull legs up and lock into place. Adjust length of legs by squeezing the prongs on the crossbar together while pulling up on the lower section of the legs. There are three different adjustments; the longer the legs the faster the balls will go when playing the game. We find that the middle position is best for most play.

Step 3:

After legs are in desired position, ensure cross braces are secured by pushing down firmly until they snap into place.

Step 4:

Turn Game onto its side and open by pulling down on the pin (A) and pulling the sides apart. Completely unfold the game and secure the top and bottom section to each other with the clasp on the back.




Fig. 2: Step 4, Opening game

Step 5:

Lift game into upright position.

Step 6:

Load balls into upper right slot, and launch by pulling down on the lever and releasing.

979-778-1400

www.wertzwerkz.net