

**Highway 55 Rental and Sales, Inc.**  
**763-478-6448**

**Moonwalk Safety and Setup Instructions**

1. Unroll inflatable and stake the 4 corners
2. Connect the blower to the inlet tube and tighten the tube around the mouth of the blower with the strap
3. Make sure that the zipper is closed before turning on power. This is normally located near the inflation tube.
4. Plug blower motor into a clean **20 amp** outlet. **Do not use additional cords.**
5. Turn on power and the inflatable will inflate in about 2 minutes

**Teardown**

1. Shut off blower motor and remove it from the inflatable
2. Allow the inflatable to deflate on it's own for about 10 minutes and pull stakes from the ground
3. Fold inflatable from each side toward the center, making sure to leave the inflation tube on the outside. Roll it up toward the inflation tube, forcing out remaining air.

